




ASSEMBLY INSTRUCTION

- SCFX-TOP | Sealing Cap for female XLR TOP Cable Connector
- SCMX-TOP | Sealing Cap for male XLR TOP & etherCON TOP Cable Connector
- SCNAC-FX | Sealing Cap for female powerCON TRUE1 TOP
- SCNAC-MX | Sealing Cap for male powerCON TRUE1 TOP

EXAMPLE OF SEALING CAP ASSEMBLY

Rear mountable when cable is assembled.




Put on of the sealing cap with keying for correct mounting (except SCMX-TOP).

SCFX-TOP



SCMX-TOP



SCNAC-FX



SCNAC-MX



Find more details on www.neutrik.com



Neutrik AG LI T: +423 / 237 24 24 F: +423/232 53 93
 Neutrik Americas Inc. USA T: +1 704 / 972 3050 F: +1 704/438 9202
 Neutrik (UK) Ltd. UK T: +44 1983 / 811 441 F: +44 1983/811 439
 Neutrik Vertriebs GmbH DE/NL/AT/DK T: +49 8131 / 280 890 F: +49 8131/280 830

Neutrik France FR T: +33 1/4131 6750 F: +33 1/4131 0511
 Neutrik Tokyo Ltd. JP T: +81 3/3663 4733 F: +81 3/3663 4796
 Neutrik Hong Kong Ltd. HK T: +852/2687 6055 F: +852/2687 6052

Draft. Nr.: BDA 657 V1 | Update: 2022-09-06 | Data subject to change without prior notice. © 2022 NEUTRIK®, NEUTRIK® are registered trademark of Neutrik AG. ALL RIGHTS RESERVED.

www.neutrik.com

NEUTRIK®